myTEM SmartHome



myTEM Dimmer Modul MTDIM-100

The dimmer module MTDIM-100 from mvTEM extends your smart home system with switching and dimming functions for incandescent or halogen lamps. The digital inputs are independent, but can be assigned directly to the outputs if desired.

The programmable behavior allows a flexible use of the device in the house.

This device is not a toy. Please keep it away from

Please read the manual before attempting to in-

These instructions are part of the product and

This word indicates a hazard with a risk that, if not avoided, can result in death or serious injury. Work on

the device must only be carried out by persons with

SAFETY INSTRUCTIONS

- · Operate this device only as described in the manual.
- Do not operate this device if it has obvious damage.
- · This device shall not be altered, modified or opened.
- This device is intended for use in buildings in a dry, dust-free location
- This device is intended for installation in a control cabinet. After installation, it must not be openly accessible
- Electrical equipment may only be installed and fitted by qualified electricians who are familiar with and comply with the applicable regulations and standards.
- Digital inputs, CAN bus and device supply must comply with the ELV requirements. Do not connect ELV and mains voltage together. (ELV = extra-low voltage)
- Do not connect any lights with integrated dimmer. Otherwise the device may be damaged.
- Do not connect any LED or compact fluorescent lamps that are not specifically designed for dimming. Otherwise the device may be damaged.
- When operating with inductive transformers, protect them according to the manufacturer's instructions on the primary side. Only use safety isolating transformers according to IEC/EN 61558-2-6.

Applications:

Functions

CAN bus

switches

DI8 (VDIout)

commissioning

on a 35 mm DIN rail

+ 24V

+ 24V

GND

GND

CAN-

CAN +

LED

← L 01

►N01

- N

ing or trailing edge control

for further wiring

- Switching and dimming of incandescent or halogen lamps
- · Switching and dimming of dimmable inductive transformers with halogen or LED lamps
- Operation by means of buttons, sensors via the central server

Supply voltage 24 VDC ± 10% with support terminals

8 digital inputs 24 VDC (DI1 – DI8) for e.g. external

24 VDC power supply, 100 mA, for digital inputs DI1 –

4 analogue outputs (AO1 – AO4), selectable for lead-

Manual positions of the outputs via DIP switch for easy

· The device is installed in a control cabinet, mounted

Installation

WARNING! Depending on national safety standards, only authorized and/or trained technicians may be allowed to perform electrical installations on the power grid. Please inform yourself about the legal situation before installation

WARNING! The device is not suitable for a shutdown, i.e. it does not provide disconnection or interruption. Even when the device is switched off, the load is not galvanically isolated from the mains

WARNING! If the set operating mode and load type do not match, there is a risk of destruction. Set the correct operating mode before connecting or replacing the load

Please install the device according to the following steps:

- WARNING! Make sure that the device is disconnected from the power supply or that the devices in the control cabinet are disconnected from the mains.
- 2. WARNING! Connect the device according to the circuit diagram of the mvTEM ProgTool or the terminal assignment from the picture above. Incorrect wiring can result in injury or death or damage the device.
- CAUTION! The device shall only be operated with stabilized power supplies (24 VDC). Connecting to higher voltages will damage the device.
- 4. The last device on the CAN bus requires the terminating resistor of 120 Ω enclosed with the myTEM Smart Server via terminals (CAN +/-).
- 5. WARNING! Switch on the power supply and, if necessary, check the wiring with the manual positions via the DIP switch. Take care of your safety as the devices are live.

Manual positions via DIP switch

With the aid of the DIP switch, the outputs can be checked after installation.

- CAUTION! While manual settings are used, the control commands from the myTEM Smart Server or myTEM Radio Server are ignored.
- CAUTION! Before starting, set all DIP switches to position OFF, i.e. upwards. This avoids that e.g. OPEN / CLOSE commands are set at the same time.
- With the DIP switches 1 4 you can now switch the analogue outputs AO1 - AO4 from 0 % to 100%.

After a power failure, all outputs are switched off until the new settings are received from the myTEM Smart Server or myTEM Radio Server.

Quick trouble shooting

The following hints may help solving trouble:

- 1. Make sure that the power supply is connected with the correct polarity. With wrong polarity the device does not start.
- 2. If a device cannot establish communication to the myTEM Smart Server or myTEM Radio Server, check if the CAN bus (+/-) is correctly wired and the ground (GND) is connected. A missing ground connection (usually available via power supply) can affect the communication.
- 3. If a device cannot establish communication to the mvTEM Smart Server or mvTEM Radio Server. check whether the terminating resistor of 120 Ω at the last device is connected to the CAN bus. If missing, please add it via terminals (CAN +/-).

Further information can be found on our website: DISCLAIMER www.mytem-smarthome.com/web/en/downloads/

Trademarks

All rights reserved. This is a translation from the original version in German

This manual may not be reproduced in any format, either in whole or in part, nor may it be duplicated or edited by electronic, mechanical or chemical means, without the written consent of the publisher.

The manufacturer, TEM AG, is not liable for any loss or damage caused by failure to follow the instructions in the manual.

Typographical and printing errors cannot be excluded. However, the information contained in this manual is reviewed on a regular basis and any necessary corrections will be implemented in the next edition. We accept no liability for technical or typographical errors or the consequences thereof. Changes may be made without prior notice as a result of technical advances. TEM AG reserves the right to make changes to product design. layout and driver revisions without notice to its users. This version of the manual supersedes all previous versions.








→ N

→L AO

← L 04 →L AC



product names mentioned herein may be trademarks or registered trademarks of their respective companies.

CAUTION!

WARNING!

ATTENTION:

children and animals!

must remain with the end user.


Warning and safety instructions

the necessary training or instruction.

stall the device!

This word warns of possible damage to property.





Sw GND

DI

To check the outputs set DIP switch 6 down to ON.

Behavior after power failure

LED display

LED red:

LED off:

The LED next to the CAN connector may show the following states:

LED green: Device started and connection to the mvTEM Smart Server or myTEM Radio Server in order

Device started but no connection with

the myTEM Smart Server or myTEM

Device not powered, not started or

LED flash- Device is in manual position ing green:

Radio Server

broker

Configuration


The products can be used immediately after being added to the Smart Home network. However, depending on the function, a configuration may be helpful or required. After setting the parameters, further optional corrections such as offset, etc. are sometimes possible.

CAUTION! Depending on the function, the server may change some settings.

Description	Settings	
Analog outputs	Leading-edge	Trailing-edge

Technical specifications

Dimensions (W × H × D)	160.5 x 101.1 x 62.5 mm (height with connectors 106.8 mm)	
Installation / mounting	On 35 mm DIN rail	
Operating voltage	24 VDC ± 10%	
Power consumption in standby	Device for continuous operation, no standby mode	
Power consumption in operation	0.4 W, if all inputs are open and all outputs are turned off 1.6 W, if all inputs are short-circuited to VDlout and all outputs are turned on	
Load	4x 250 W, for resistive, capacitive and inductive loads, maximum cable length 20 m	
Power supply for digital inputs	24 VDC, 100 mA	
Ambient temperature for operation	0 °C – 50 °C	
Ambient temperature for storage	-20 °C – 60 °C	
Ambient humidity	5 %RH – 85 %RH (non condensing)	
Wire cross-section connectors	0.25 mm² – 2.5 mm²	
Stripping length for connectors	ca. 7 mm	
Tightening torque for connectors	0.5 Nm	
Degree of protection provided by enclosure	IP 20 (after installation)	(according to EN 60529)
Protection class	П	(according to EN 60730-1)
Overvoltage category	П	(according to EN 60730-1, resp. EN 60664-1)
Pollution degree	2	(according to EN 60730-1)
Electrical safety	EN 60730-1:2016 + A1:2019	
EMC	EN 60730-1:2016 + A1:2019 EN IEC 61000-6-2:2019	EN 61000-6-3:2007 + A1:2011 / AC:2012
RoHS	EN IEC 63000:2018	
CE conformity	2014/35/EU (LVD) 2014/30/EU (EMC)	2011/65/EU (RoHS)





Belegungsplan / Assignment plan / Plan d'affectation / Piano di assegnazione

